



Tire Fitment Guide

2008

IMPORTANT TIRE GUIDE INFORMATION

PLEASE READ!

This guide is presented as a sales aid for the Mickey Thompson Tire line only. These suggestions are a starting point in discussing the minimum required changes to a vehicle in order to fit Mickey Thompson Baja Series Tires. These suggestions in no way express or imply the safety or fitness of the vehicle or minimum changes required.

CAUTION!

If changing the overall tire diameter from the original equipment, the speedometer accuracy and anti-lock brake system (ABS) may be affected. Vehicles should not be fitted with wheel diameters that are smaller than the original equipment wheel diameter because they may interfere with brake and suspension components.

This guide is presented as a sales aid for the Mickey Thompson Tire line only. These suggestions are a starting point in discussing the minimum required changes to a vehicle in order to fit Mickey Thompson Baja Series Tires. These suggestions in no way express or imply the safety or fitness of the vehicle or minimum changes required.

FITMENT GUIDE LEGEND:														
T - FENDER TRIM REQUIRED	F - FENDER CUT / CUT OUT FLARES REQUIRED					W - O.E. OR POSITIVE OFFSET WHEELS REQUIRED								
Appx. Tire Diameter >>	28"	30"	31"	32"	33"	33"-34"	34"-35"	36"-37"	38"-39"	39-40"				
DIRECTIONS: Find vehicle below - desired size(s) to the right. Changes required, if any, are described in the legend.	28x9.50-All 225/75R16	30x9.50-All	31x10.50-All 245/75R16 245/70R17	31x11.50-All 265/75R16	32x11.50R15 235/85R16 265/70R17 275/65R18	33x11.50-All 285/75R16 285/70R17 275/70R18	33x12.50-All 305/70R16 305/60R18 305/55R20	33x13.50-All 325/60R18	34x11.50-All 33x15.50-All	35x12.50-All 315/75R16 315/70R17 305/70R18	35x13.50-All 325/65R18	36x14.50-All 36x15.50-All 37x12.50-All 37x13.50-All	38x15.50-All 38.5x14.50R20	40x13.50-All
CHEVY/GMC 2WD														
82 - 93 S10 / T10 P/U's, SUV's	0" (W)	2" (T)	2" (T)	3"	3"	6"	6"	6"	---	---	---	---	---	---
94 - 04 S10 / T10 P/U's, SUV's	0" (W)	2" (T)	2" (T)	3"	3"	6"	6"	6"	---	---	---	---	---	---
73 - 91 Blazer, Jimmy, Suburban 1/2 ton	---	0"	0" (W)	2"	2"	4"	6"	6"	7"	8"	9"	9" (T)	---	---
92 - 99 Blazer, Yukon, Tahoe	---	0"	0" (W)	0" (W)	2"	4"	6"	6"	7"	8"	9"	9" (T)	---	---
00 - 08 Tahoe, Yukon, Yukon XL, Suburban 1500 and Avalanche	---	---	0" (W)	0" (W)	0" (W)	2"	4"	4"	6"	6"	7" (T)	9" (T)	---	---
73 - 87 C20, C30, Suburban 3/4 ton	---	0"	0"	0" (W)	0" (W)	2"	2"	3"	5"	6"	6" (W)	---	---	---
88 - 98 C1500 P/U	---	0"	0" (W)	0" (W)	2"	4"	6"	6"	7"	8"	9"	9" (T)	---	---
88 - 98 C2500, C3500, Suburban 2500	---	---	0"	0"	0" (W)	2"	4"	4" (T)	6"	6" (T)	8"	9"	---	---
99 - 06 Silverado / Sierra 1500	---	---	0" (W)	0" (W)	0" (W)	2"	4"	4"	6"	6"	7" (T)	9" (T)	---	---
07 - 08 Silverado / Sierra 1500	---	---	0" (W)	0" (W)	0" (W)	2"	4"	4" (T)	6"	6" (T)	8"	9"	---	---
99 - 08 Silverado / Sierra 1500HD,2500,3500	---	---	0" (W)	0" (W)	0" (W)	2"	4"	4" (T)	6"	6" (T)	6" (T)	---	---	---
04 - 08 Colorado / Canyon Z71, Z85	0"	0" (W)	2"	2" (W)	2" (W)	3"	3"	4"	---	---	---	---	---	---
CHEVY/GMC 4WD														
82 - 93 S10 / T10 P/U's, SUV's	0" (W)	1.5"	4"	3" (F)	4" (F)	4" (F)	6" (F)	7" (F)	---	---	---	---	---	---
94 - 04 S10 / T10 P/U's, SUV's	0"	0"	2"	2" (F)	4" (F)	4" (F)	6" (F)	7" (F)	---	---	---	---	---	---
02 - 08 Trailblazer/ Equinox/ Envoy	0" (W)	0" (W)	---	---	---	---	---	---	---	---	---	---	---	---
73 - 91 K-5 Blazer, Jimmy, Suburban	---	0"	0"	0"	2"	2"	3"	4"	4"	4" (F)	4" (F)	6" (F)	10"	10" (F)
92 - 99 Blazer, Yukon, Tahoe	---	---	0"	0"	2"	2"	4"	4" (T)	6"	6" (T)	8"	9"	9" (F)	10" (F)
00 - 06 Tahoe, Yukon, Yukon XL, and Avalanche	---	---	0"	0"	0"	2"	2" (W)	4"	4" (W)	6"	6" (W)	7" (T)	9" (T)	---
07 - 08 Tahoe, Yukon, Yukon XL, and Avalanche	---	---	---	---	0"	0"	2"	2"	4"	6" (T)	6" (T)	---	---	---
92 - 99 Suburban	---	---	0"	0"	2"	2"	4"	4" (T)	6"	6" (T)	8"	9"	9" (F)	10" (F)
00 - 06 Suburban	---	---	0"	0"	2"	3"	4" (W)	4" (W)	4" (W)	6"	6" (W)	7" (T)	9" (T)	---
07 - 08 Suburban	---	---	0"	0"	0"	2"	4"	4" (T)	6"	6" (T)	6" (T)	---	---	---
73 - 87 K 10, 20, 30	---	---	0"	0"	2"	2"	3"	4"	4"	4" (F)	4" (F)	6" (F)	10"	10" (F)
88 - 98 K 1500, 2500, K3500	---	---	0"	0"	2"	2"	4"	4" (T)	6"	6" (T)	8"	9"	9" (F)	10" (F)
99 - 06 Silverado / Sierra 1500	---	---	0" (W)	0" (W)	0" (W)	2"	4"	4" (T)	6" (T)	6" (T)	6" (T)	---	---	---
07 - 08 Silverado / Sierra 1500	---	---	0" (W)	0" (W)	0" (W)	2"	2" (T)	4" (T)	6" (T)	6" (T)	6" (T)	---	---	---
99 - 08 Silverado / Sierra 1500HD,2500,3500	---	---	0" (W)	0" (W)	0" (W)	2"	2" (T)	4" (T)	6"	6" (T)	6" (T)	8"	9" (F)	---
04 - 08 Colorado Z85	---	---	0"	0" (W)	4"	4"	---	---	---	---	---	---	---	---
04 - 08 Colorado Z71	---	---	0" (W)	0" (W)	2"	4"	---	---	---	---	---	---	---	---
DODGE 2WD														
87 - 96 Dakota	0" (W)	2"	2" (T) (W)	2" (F) (W)	---	---	---	---	---	---	---	---	---	---
97 - 04 Dakota	0" (W)	2" (W)	3"	3" (W)	5"	6"	6" (T)	6" (F)	---	---	---	---	---	---
05 - 08 Dakota	---	---	0"	---	0" (W)	---	---	---	---	---	---	---	---	---
98 - 03 Durango	0" (W)	2" (W)	3"	3" (W)	5"	6"	6" (T)	6" (F)	---	---	---	---	---	---
04 - 08 Durango	---	---	0"	---	0" (W)	---	---	---	---	---	---	---	---	---
76 - 93 1/2T P.U., Ramcharger	0"	0" (W)	3"	3" (W)	4"	5"	5" (T)	---	---	---	---	---	---	---
76 - 93 3/4T, 1T P.U.	---	---	0"	0" (W)	2"	3"	5"	5" (T)	---	---	---	---	---	---
94 - 01 Ram 1500	---	0"	2"	3"	4"	5"	6"	6.5" (W)	8.5"	9.5"	9.5" (W)	---	---	---
02 - 08 Ram 1500	---	---	0"	---	2"	3"	5"	6"	7"	9"	9.5" (W)	12"	---	---
94 - 01 Ram 2500, 3500	---	---	0"	0" (W)	2"	3"	5"	6"	7"	9"	9.5" (W)	12"	---	---
02 - 08 Ram 2500, 3500	---	---	0"	---	0"	0" (W)	2"	2" (W)	4" (W)	4" (W)	7"	7" (W)	---	---

WHEEL WIDTH PLAYS A PART IN TIRE FITMENT / CLEARANCE, USE YOUR BEST JUDGEMENT IN CHOOSING WHEEL WIDTH / BACKSPACING. CHOOSE A WHEEL DIAMETER THAT IS EQUAL OR GREATER THAN THE ORIGINAL EQUIPMENT DIAMETER.

(T) = Fender trim required (F) Fender flares required (W) OE or Positive Offset Wheels Required.
Wheel width plays a part in tire fitment / clearance. Use your best judgement in choosing wheel width.

This guide is presented as a sales aid for the Mickey Thompson Tire line only. These suggestions are a starting point in discussing the minimum required changes to a vehicle in order to fit Mickey Thompson Baja Series Tires. These suggestions in no way express or imply the safety or fitness of the vehicle or minimum changes required.

FITMENT GUIDE LEGEND:														
T - FENDER TRIM REQUIRED	F - FENDER CUT / CUT OUT FLARES REQUIRED					W - O.E. OR POSITIVE OFFSET WHEELS REQUIRED								
Appx. Tire Diameter >>	28"	30"	31"	32"	33"	33"-34"	34"-35"	36"-37"	38"-39"	39-40"				
DIRECTIONS: Find vehicle below - desired size(s) to the right. Changes required, if any, are described in the legend.	28x9.50-All 225/75R16	30x9.50-All	31x10.50-All 245/75R16 245/70R17	31x11.50-All 265/75R16	32x11.50R15 235/85R16 265/70R17 275/65R18	33x11.50-All 285/75R16 285/70R17 275/70R18	33x12.50-All 305/70R16 305/60R18 305/55R20	33x13.50-All 325/60R18	34x11.50-All 33x15.50-All	35x12.50-All 315/75R16 315/70R17 305/70R18	35x13.50-All 325/65R18	36x14.50-All 36x15.50-All 37x12.50-All 37x13.50-All	38x15.50-All 38.5x14.50R20	40x13.50-All
DODGE 4WD														
87 - 96 Dakota	0" (W)	2"	4"	4" (T)	6"	6"	7"	7" (F)	---	---	---	---	---	---
97 - 04 Dakota	---	0"	0" (W)	2"	2" (T)	3" (T)	6"	6" (T)	---	---	---	---	---	---
05 - 06 Dakota	---	---	0"	0"	2"	---	---	---	---	---	---	---	---	---
98 - 03 Durango	---	0"	0" (W)	2"	2" (T)	3" (T)	6"	6" (T)	---	---	---	---	---	---
04 - 08 Durango	---	---	0"	---	---	0"	2"	---	---	---	---	---	---	---
76 - 93 P.U., Ramcharger	0"	0"	0"	0" (T)	2" (T)	2" (T)	3" (T)	4" (T)	4" (T)	6" (T)	8" (T)	9" (T)	9" (F)	9" (F)
94 - 01 Ram 1500	---	---	0"	0"	0" (W)	0" (W)	0" (W)	3"	4"	4" (T)	6"	5" (F)	7" (T)	8" (F)
02 - 08 Ram 1500	---	---	0"	0"	0"	0"	0" (W)	4"	4"	6"	8"	9" (T)	---	---
94 - 01 Ram 2500, 3500	---	---	0"	0"	0"	0"	0"	0" (W)	4"	6"	6"	8"	9"	8" (T)
02 - 08 Ram 2500, 3500	---	---	0"	---	0"	0"	0" (W)	0" (W)	3"	4"	6"	8"	---	---
FORD 2WD														
83 - 92 Ranger, Bronco II	2"	3"	6"	6" (W)	8"	8" (W)	9"	9" (T)	9" (F)	9" (F)	9" (F) (W)	---	---	---
93 - 97 Ranger	0" (W)	2"	4" (W)	4" (W)	6"	8"	9"	9" (W)	9" (T)	9" (T)	9" (F)	---	---	---
98 - 08 Ranger	0" (W)	2"	4" (W)	4" (W)	6"	7"	7" (W)	7" (W)	7" (T) (W)	7" (T) (W)	---	---	---	---
01 - 08 Escape	0"	2"	---	---	---	---	---	---	---	---	---	---	---	---
91 - 94 Explorer	0"	0" (T)	3"	4"	6"	6"	6" (T)	6" (F)	8" (F)	9"	9" (T)	9" (F)	---	---
95 - 99 Explorer, Mountaineer	---	0"	0" (T)	---	4" (F)	4"	4" (F)	6" (F)	---	---	---	---	---	---
00 - 08 Explorer	0"	0"	0" (W)	0" (W)	---	---	---	---	---	---	---	---	---	---
01 - 08 Explorer Sport-Trac	0"	0"	0" (W)	0" (W)	2"	4"	4" (W)	4" (W)	4" (F)	7"	7"	---	---	---
65 - 79 F-100, F-150	0"	0" (W)	2"	3"	3" (T)	3" (F)	---	---	---	---	---	---	---	---
80 - 96 F-150	0"	0"	0" (W)	2"	3"	4"	6"	6" (W)	6" (T) (W)	8"	9" (W)	9" (F) (W)	---	---
97 - 08 F-150, Expedition	---	---	0" (W)	0" (W)	2"	3" (W)	6"	6" (W)	6" (T) (W)	8"	8" (W)	9" (W)	---	---
77 - 79 F-250	---	---	0"	0"	0" (W)	2"	3"	3" (W)	3" (T) (W)	3" (F) (W)	---	---	---	---
80 - 97 F-250, F-350	---	---	0"	0"	0"	2" (W)	2"	3"	4"	6"	6" (W)	9"	9" (F)	---
98 - 08 F-250, F-350 SuperDuty	---	---	0"	0"	0"	2" (W)	2"	3"	4"	6"	6" (W)	9"	9" (F)	---
00 - 05 Excursion	---	---	0"	0"	0" (W)	2"	4"	4" (W)	---	6" (W)	8"	---	---	---
FORD 4WD														
83 - 92 Ranger, Bronco II	0"	2"	4"	4"	6"	6"	6" (T)	6" (F)	8" (F)	9"	9" (T)	9" (F)	---	---
93 - 97 Ranger	---	0"	0" (W)	0" (T)	4"	4"	6" (T)	6" (T)	6" (F)	8"	9"	9" (F)	---	---
98 - 08 Ranger	---	0"	0" (W)	0" (T)	4" (F)	4" (F)	6" (T)	6" (T)	6" (F)	7" (T)	7" (F)	---	---	---
01 - 08 Escape	0"	0"	---	---	---	---	---	---	---	---	---	---	---	---
91 - 94 Explorer	0"	0" (T)	3"	4"	6"	6"	6" (T)	6" (F)	8" (F)	9"	9"	9" (F)	---	---
95 - 99 Explorer, Mountaineer	---	0"	0" (T)	---	4" (F)	4"	4" (F)	6" (F)	---	---	---	---	---	---
00 - 08 Explorer	0"	0"	0" (W)	0" (W)	---	---	---	---	---	---	---	---	---	---
01 - 08 Explorer Sport-Trac	0"	0"	0" (W)	0" (W)	2"	4"	4" (W)	4" (W)	4" (F)	7"	7"	---	---	---
66 - 77 Bronco	---	0"	3" or (F)	2" (F)	4" (F)	0" (F)	3" (F)	4" (F)	4" (F)	5" (F)	6" (F)	7" (F)	9" (F)	---
78 - 79 Bronco	0"	0"	0"	0" (T)	3"	0"	2"	4"	3"	3"	4" (T)	5" (F)	8" (T)	9" (T)
80 - 96 Bronco	0"	0"	0"	0"	4"	0" (W)	3"	4"	6"	6"	8"	9"	9" (F)	9" (F)
65 - 79 F-100, F-150	---	0"	0"	0"	3"	3"	4"	4" (T)	4" (T)	5" (T)	5" (F)	7" (F)	8" (F)	9" (F)
80 - 96 F-150	---	0"	0"	0"	3"	2" (W)	3"	4"	6"	6"	8"	9"	9" (F)	9" (F)
97 - 08 F-150, Expedition	---	---	0"	0"	---	2" (W)	2" (W)	2"	4"	6"	6" (T)	8"	8" (T)	9" (F)
77 - 79 F-250	---	---	---	0"	---	2"	0" (W)	2"	4"	4"	4" (T)	6"	8"	9" (T)
80 - 97 F-250, F-350	---	---	---	---	---	4"	4" (W)	4"	4" (T)	4"	4" (T)	6" (T)	9"	9" (F)
98 - 08 F-250, F-350 SuperDuty	---	---	---	---	---	2"	2"	2"	4"	4"	4"	6" (T)	8" (T)	11"
00 - 05 Excursion	---	---	---	0"	0"	2"	2"	2"	4"	4"	4"	6" (T)	8" (T)	11"

(T) = Fender trim required (F) Fender flares required (W) OE or Positive Offset Wheels Required.
Wheel width plays a part in tire fitment / clearance. Use your best judgement in choosing wheel width.

This guide is presented as a sales aid for the Mickey Thompson Tire line only. These suggestions are a starting point in discussing the minimum required changes to a vehicle in order to fit Mickey Thompson Baja Series Tires. These suggestions in no way express or imply the safety or fitness of the vehicle or minimum changes required.

FITMENT GUIDE LEGEND:														
T - FENDER TRIM REQUIRED	F - FENDER CUT / CUT OUT FLARES REQUIRED					W - O.E. OR POSITIVE OFFSET WHEELS REQUIRED								
Appx. Tire Diameter >>	28"	30"	31"	32"	33"	33"-34"	34"-35"	36"-37"	38"-39"	39-40"				
DIRECTIONS: Find vehicle below - desired size(s) to the right. Changes required, if any, are described in the legend.	28x9.50-All 225/75R16	30x9.50-All	31x10.50-All 245/75R16 245/70R17	31x11.50-All 265/75R16	32x11.50R15 235/85R16 265/70R17 275/65R18	33x11.50-All 285/75R16 285/70R17 275/70R18	33x12.50-All 305/70R16 305/60R18 305/55R20	33x13.50-All 325/60R18	34x11.50-All 33x15.50-All	35x12.50-All 315/75R16 315/70R17 305/70R18	35x13.50-All 325/65R18	36x14.50-All 36x15.50-All 37x12.50-All 37x13.50-All	38x15.50-All 38.5x14.50R20	40x13.50-All
GM - HUMMER														
H1 / Humvee	---	---	---	---	---	---	---	---	---	0"	0"	0"	---	---
03 - 08 H2	---	---	---	---	---	---	---	---	---	0"	4"	6"	8"	9"
05 - 08 H3	---	---	---	0"	0"	0"	---	---	---	4"	4"	6"	---	---
HONDA 4WD														
97 - 02 Honda Passport	---	0"	0"	0" (T)	2" (T)	---	---	---	---	---	---	---	---	---
03 - 08 Honda Pilot	---	---	0"	---	---	---	---	---	---	---	---	---	---	---
06 - 08 Ridgeline	---	---	0"	---	---	---	---	---	---	---	---	---	---	---
ISUZU 4WD														
83 - 95 Isuzu Pickup	0" (T)	2" (T)	3" (W)	3" (T) (W)	---	---	---	---	---	---	---	---	---	---
84 - 00 Isuzu Amigo	---	---	---	---	---	---	---	---	---	---	---	---	---	---
98 - 04 Isuzu Rodeo	---	0"	0"	0" (T)	2" (T)	---	---	---	---	---	---	---	---	---
84 - 96 Isuzu Trooper II	---	---	---	---	---	---	---	---	---	---	---	---	---	---
96 - 00 Isuzu Hombre	---	0"	---	---	---	---	---	---	---	---	---	---	---	---
JEEP 2WD & 4WD														
06 - 08 Commander	---	---	0" (W)	---	2" (W)	4"	4"	4" (W)	4" (W)	---	---	---	---	---
93 - 98 Grand Cherokee	0"	0"	2" (W)	3" (T)	4" (T)	4" (F)	6" (F)	---	---	---	---	---	---	---
05 - 08 Grand Cherokee	---	---	0"	0" (W)	0" (W)	4"	4"	4" (W)	4" (W)	---	---	---	---	---
84 - 01 Cherokee XJ	0"	3"	3" (W)	3" (T) (W)	4" (F) (W)	6" (F) (W)	6" (F) (W)	6" (F) (W)	8" (F)	8" (F) (W)	---	---	---	---
87 - 96 Wrangler YJ	0"	0"	2"	2" (F)	4"	4"	5"	6"	7"	6" (F)	7" (F)	8" (F)	---	---
97 - 06 Wrangler TJ	---	---	0" (W)	2"	2" (T)	2.5"	4" (T)	4" (F)	4" (F)	6" (F)	7" (F)	8" (F)	---	---
07 - 08 Wrangler JK	---	0"	0"	0" (W)	0" (W)	2"	2.5"	4"	4" (W)	4"	5" (W)	9"	---	---
07 - 08 Sahara & Rubicon	---	---	---	0" (W)	0" (W)	2"	2.5"	4"	4" (W)	4"	5" (W)	9"	---	---
55 - 86 CJ 5, 6, 7, 8	0"	0"	0" (W)	2"	2.5" (F)	4"	4" (T)	4" (F)	6"	6" (F)	6" (F)	7" (F)	---	---
02 - 08 Liberty	0"	0"	---	---	---	---	---	---	---	---	---	---	---	---
MAZDA 2WD														
94 - 97 B4000 Series	0" (W)	2"	4" (W)	4" (W)	6"	8"	9"	9" (W)	9" (T)	9" (T)	9" (F)	---	---	---
98 - 05 Pickup	0" (W)	2"	4" (W)	4" (W)	6"	7"	7" (W)	7" (W)	7" (T) (W)	7" (T) (W)	---	---	---	---
01 - 08 Tribute	0"	0"	---	---	---	---	---	---	---	---	---	---	---	---
MAZDA 4WD														
78 - 86 Pickup	2" (T)	2" (F)	2" (F)	2" (F)	---	---	---	---	---	---	---	---	---	---
87 - 92 Pickup	---	0"	0" (T)	2" (T)	2" (T)	3" (T)	3" (F)	---	---	---	---	---	---	---
94 - 97 B4000 Series	---	---	0"	0" (T)	---	4"	6" (T)	6" (T)	6" (F)	8"	9" (T)	9"	---	---
98 - 05 Pickup	---	0"	0" (W)	0" (W)	4" (F)	4" (F)	6" (T)	6" (T)	6" (F)	7" (T)	7" (F)	---	---	---
01 - 08 Tribute	0"	0"	---	---	---	---	---	---	---	---	---	---	---	---
MITSUBISHI 4WD														
82 - 86 Pickup	0" (W)	2" (F)	2"	2" (F)	4" (T)	---	---	---	---	---	---	---	---	---
87 - 92 Pickup	0"	2"	2"	2" (F)	4" (T)	---	---	---	---	---	---	---	---	---
01 - 08 Endeavor	---	---	0" (W)	---	0" (W)	---	---	---	---	---	---	---	---	---
84 - 92 Montero	0"	2"	2" (T)	2"	---	---	---	---	---	---	---	---	---	---
93 - 04 Montero	0"	0"	0" (W)	2" (W)	---	---	---	---	---	---	---	---	---	---
05 - 08 Montero	---	---	---	---	0" (W)	---	---	---	---	---	---	---	---	---
06 - 08 Raider	---	---	0"	0"	0" (W)	---	---	---	---	---	---	---	---	---

WHEEL WIDTH PLAYS A PART IN TIRE FITMENT / CLEARANCE, USE YOUR BEST JUDGEMENT IN CHOOSING WHEEL WIDTH / BACKSPACING. CHOOSE A WHEEL DIAMETER THAT IS EQUAL OR GREATER THAN THE ORIGINAL EQUIPMENT DIAMETER.

(T) = Fender trim required (F) Fender flares required (W) OE or Positive Offset Wheels Required.
Wheel width plays a part in tire fitment / clearance. Use your best judgement in choosing wheel width.

This guide is presented as a sales aid for the Mickey Thompson Tire line only. These suggestions are a starting point in discussing the minimum required changes to a vehicle in order to fit Mickey Thompson Baja Series Tires. These suggestions in no way express or imply the safety or fitness of the vehicle or minimum changes required.

FITMENT GUIDE LEGEND:														
T - FENDER TRIM REQUIRED	F - FENDER CUT / CUT OUT FLARES REQUIRED					W - O.E. OR POSITIVE OFFSET WHEELS REQUIRED								
Appx. Tire Diameter >>	28"	30"	31"	32"	33"	33"-34"	34"-35"	36"-37"	38"-39"	39-40"				
DIRECTIONS: Find vehicle below - desired size(s) to the right. Changes required, if any, are described in the legend.	28x9.50-All 225/75R16	30x9.50-All	31x10.50-All 245/75R16 245/70R17	31x11.50-All 265/75R16	32x11.50R15 235/85R16 265/70R17 275/65R18	33x11.50-All 285/75R16 285/70R17 275/70R18	33x12.50-All 305/70R16 305/60R18 305/55R20	33x13.50-All 325/60R18	34x11.50-All 33x15.50-All	35x12.50-All 315/75R16 315/70R17 305/70R18	35x13.50-All 325/65R18	36x14.50-All 36x15.50-All 37x12.50-All 37x13.50-All	38x15.50-All 38.5x14.50R20	40x13.50-All
NISSAN 2WD														
78 - 86 Pickup	2" (W)	3" (W)	6" (T)	---	---	---	---	---	---	---	---	---	---	---
87 - 97 Pickup	2"	3"	6" (W)	---	---	---	---	---	---	---	---	---	---	---
86 - 97 Pathfinder	0"	0" (W)	0" (W)	2"	4" (T)	0" (T)	4" (T)	---	---	---	---	---	---	---
98 - 04 Pathfinder	0"	0"	2" (W)	---	---	---	---	---	---	---	---	---	---	---
00 - 04 Frontier Pickup	2"	3"	6" (W)	---	---	---	---	---	---	---	---	---	---	---
04 - 08 Titan and Armada	---	---	0"	---	0" (W)	0" (W)	4" (W)	6"	6" (W)	8"	8" (W)	---	---	---
00 - 04 Xterra	0"	0"	0" (W)	3"	3" (W)	5"	5" (W)	---	---	---	---	---	---	---
NISSAN 4WD														
78 - 86 Pickup	2"	2" (T)	2" (F)	2" (F)	---	---	---	---	---	---	---	---	---	---
87 - 97 Pickup	0"	0" (W)	0" (W)	2"	2" (F)	0" (T)	4" (T)	---	---	---	---	---	---	---
86 - 97 Pathfinder	0"	0" (W)	0" (W)	2"	4" (T)	0" (T)	4" (T)	---	---	---	---	---	---	---
98 - 04 Pathfinder	0"	0"	2"	---	---	---	---	---	---	---	---	---	---	---
00 - 04 Frontier Pickup	---	0"	2"	3"	3" (W)	5"	5" (W)	---	---	---	---	---	---	---
04 - 08 Titan and Armada	---	---	---	---	---	0"	2.5"	4"	---	6"	8"	10"	---	---
00 - 04 Xterra	0"	0"	0" (W)	3"	3" (W)	5"	5" (W)	---	---	---	---	---	---	---
05 - 08 Xterra	---	0"	0"	0" (T)	3"	5"	5" (W)	---	---	---	---	---	---	---
SUZUKI														
86 - 91 Samurai	3" (W)	3" (F) (W)	6"	6" (F)	---	---	---	---	---	---	---	---	---	---
89 - 00 Sidekick	0" (F)	0" (F) (W)	2.5" (T)	---	---	---	---	---	---	---	---	---	---	---
TOYOTA 2WD														
79 - 85 Pickup	3"	3" (W)	6" (W)	6" (T) (W)	---	---	---	---	---	---	---	---	---	---
86 - 94 Pickup	2"	3"	6"	6" (T) (W)	---	---	---	---	---	---	---	---	---	---
95 - 08 Tacoma (inc. Pre-Runner Pkg)	2"	3"	6"	6" (T)	---	---	---	---	---	---	---	---	---	---
95 - 98 T-100	---	---	0"	0" (W)	2"	4"	7"	7" (W)	---	---	---	---	---	---
00 - 06 Tundra	---	---	0"	0" (W)	2"	4"	7"	7" (W)	8"	9"	9" (W)	---	---	---
07 - 08 Tundra	---	---	---	---	0"	2.5"	2.5"	---	---	---	---	---	---	---
95 - 00 4-Runner	---	0"	0"	0" (W)	3"	4"	4"	4" (T)	4" (F)	7" (T)	7"	8" (F)	---	---
01 - 04 4-Runner	---	---	---	0"	3"	4"	4"	4" (T)	4" (F)	7" (T)	7"	8" (F)	---	---
01 - 08 Highlander	0"	0" (W)	---	---	---	---	---	---	---	---	---	---	---	---
01 - 08 Sequoia	---	---	---	0" (W)	---	---	---	---	---	---	---	---	---	---
99 - 08 Rav4	0" (W)	0" (W)	---	---	---	---	---	---	---	---	---	---	---	---
07 - 08 FJ Cruiser	---	---	---	---	0"	3"	3"	---	---	---	---	---	---	---
TOYOTA 4WD														
79 - 85 Pickup	0"	0"	0" (W)	2"	3"	3"	4"	5"	4" (T)	6"	7"	8" (F)	10" (F)	11" (F)
86 - 94 Pickup	0"	0"	0" (W)	2"	3"	3"	4"	4" (T)	4" (F)	7" (T)	7" (T)	8" (F)	8" (F)	---
95 - 08 Tacoma (inc. Pre-Runner Pkg)	---	0"	0"	0" (W)	3"	3"	6"	6"	7"	8"	8"	---	---	---
95 - 98 T-100	---	0"	0"	0" (T)	2" (T)	2"	4"	4" (T)	4" (F)	6"	6" (T)	7"	7" (F)	---
00 - 06 Tundra	---	0"	0"	0" (T)	2" (T)	2"	4"	4" (T)	4" (F)	6"	6" (T)	7"	7" (F)	---
07 - 08 Tundra	---	---	---	---	0"	2.5"	2.5"	---	---	---	---	---	---	---
75 - 84 FJ40 Landcruiser	---	0"	3" or (F)	2" (F)	3" (F)	2" (F)	4" (F)	6" (F)	7" (F)	7" (F)	7" (F)	---	---	---
84 - 92 FJ60 Landcruiser	---	0"	0" (W)	2" or (F)	3" (F)	3" (F)	---	---	---	---	---	---	---	---
94 - 99 Landcruiser	---	---	0" (W)	0" (W)	3" (W)	3" (W)	---	---	---	---	---	---	---	---
95 - 00 4-Runner	---	0"	0"	0" (W)	3"	4"	4"	4" (T)	4" (F)	7" (T)	7" (T)	8" (F)	---	---
01 - 04 4-Runner	---	---	---	0"	3"	4"	4"	4" (T)	4" (F)	7" (T)	7" (T)	8" (F)	---	---
01 - 08 Highlander	0"	0" (W)	---	---	---	---	---	---	---	---	---	---	---	---
01 - 08 Sequoia	0"	0"	0" (W)	0" (W)	---	---	---	---	---	---	---	---	---	---
99 - 08 Rav4	0" (W)	0" (W)	---	---	---	---	---	---	---	---	---	---	---	---
07 - 08 FJ Cruiser	---	---	---	---	0"	3"	3"	---	---	---	---	---	---	---

(T) = Fender trim required (F) Fender flares required (W) OE or Positive Offset Wheels Required.
Wheel width plays a part in tire fitment / clearance. Use your best judgement in choosing wheel width.



Mickey Thompson
Performance Tires & Wheels
4600 Prosper Drive, Stow, OH 44224
PH. (330) 928-9092 • FAX (330) 928-0503

www.mickeythompsontires.com

All specifications subject to change without notice. Not responsible for typographical errors.

PRINTED IN USA

M/T® 06/08